



How to connect the keys




J2 Player LED Guide

	● LED ON	○ LED OFF	
Player	PS4	PS3	XInput
1P			
2P			
3P			
4P			
5P			
6P			
7P			


How to connect the Breakout Board




J4 Detail




How to connect the Analog Sticks (optional purchase)



How to connect the Brook Touch Pad (optional purchase)




如何連接按鈕




J2 Player LED 連接方式

	● LED ON	○ LED OFF	
Player	PS4	PS3	XInput
1P			
2P			
3P			
4P			
5P			
6P			
7P			


如何連接 Brook 外接板




J4 連接方式



如何連接 Analog Stick (選購)




如何連接 Brook 觸控板 (選購)



说明书

Brook PS4+ 声音格斗板 连结说明书


如何连接按钮




J2 Player LED 连接方式

	● LED ON	○ LED OFF	
Player	PS4	PS3	XInput
1P			
2P			
3P			
4P			
5P			
6P			
7P			

如何连接 Brook 外接板




J4 连接方式



如何连接 Analog Stick

(选购)



如何连接 Brook 触控板

(选购)

